



CADverter for CATIA V5i to PS

Product Release Version 23.1



USER GUIDE

Revision: 2.0
Issued: 06/05/2020

Contents

Overview of CADverter	2
About Theorem	2
What is CADverter?	2
The CATIA V5i Bi-directional Parasolid Translator	3
Primary Product Features	3
Primary Product benefits?	3
Getting Started	5
Documentation	5
Installation Media	5
Installation	5
License Configuration	5
Running the Product	6
Using the Product	7
Default Translations	7
Default Translation – via the Unified Interface	7
Default Translation – via the Command Line	9
Translator Customization	11
Common Options for CATIA V5i to Parasolid	11
CATIA V5i Read Arguments	11
Parasolid Write Arguments	12
CATIA V5i to Parasolid Entity Mask Arguments	12
CATIA V5i to Parasolid General Arguments	14
Common Options for Parasolid to CATIA V5i	15
Parasolid Read Arguments	15
Catia5i Write Arguments	16
Parasolid to CATIA V5i Entity Mask Arguments	17
Parasolid to CATIA V5i General Arguments	18
Command Line Advanced Arguments	19
CATIA V5i to Parasolid Advanced Arguments	19
Parasolid to CATIA V5i Advanced Arguments	21

Overview of CADverter

About Theorem

Theorem Solutions is a world leader in the field of Engineering Data Services and Solutions. This leadership position stems from the quality of our technology and the people in the company. Quality comes not only from the skills and commitment of our staff, but also from the vigorous industrial use of our technology & services by world leading customers.




We are proud that the vast majority of the world's leading Automotive, Aerospace, Defense, Power Generation and Transportation companies and their Supply chains use our products and services daily. Working closely with our customers, to both fully understand their requirements and feed their input into our development processes has significantly contributed to our technology and industry knowledge.

Theorem Solutions is an independent UK headquartered company incorporated in 1990, with sales and support offices in the UK and USA. Theorem has strong relationships with the major CAD and PLM vendors, including; Autodesk, Dassault Systemes, ICEM Technologies (a Dassault company), PTC, SolidWorks, Spatial Technology and Siemens PLM Software. These relationships enable us to deliver best in class services and solutions to engineering companies worldwide.


What is CADverter?

CADverter is one of 5 core Theorem brands which consist of:



CADverter

Direct translation of 3D data to or from an alternate CAD, Visualization or Standards Based format



Multi-CAD

Interactive integration of non-native 3D data formats into the native CAD system



Visualize 3D

Direct translation of 3D data for the purpose of Visualization



Publish 3D

The creation of documents enriched with 3D content



Process Automation

Applications to automate any Data Exchange and collaboration processes

The CATIA V5i Bi-directional Parasolid Translator

The CATIA V5i to Parasolid CADverter is a direct database converter between CATIA V5 and Parasolid. It enables the user to convert all forms of mechanical design geometry, as well as assembly and attribute information, between these two systems without requiring access to a CATIA V5 license.

CADverter can be purchased as a uni-directional, CATIA V5i to Parasolid, or Parasolid to CATIA V5i product, or as a bi-directional product.

The translator can be invoked in batch mode with the command line interface allowing the conversion process to be integrated into any process oriented operation. Alternatively the conversion process may be operated by using the Theorem Unified Interface.

Primary Product Features

- CADverter converts all geometry
- If assembly data (product structure) is in the file, the assembly structure will be mapped between the two systems as well as colour information
- The user can filter data to optimize the process
- If you wish to visualise and interrogate the CATIA V5 or Parasolid data this can be done by using the integrated User Interface, which is included with CADverter

Primary Product benefits?

- Direct conversion between CATIA V5 and Parasolid reduces processing time, simplifies integration and retains accuracy of the model
- The integrated viewing capability enables visually verification, pre and post translation

- The integrated data filtering options allows selected data ONLY to be processed, enabling optimisation of translations and time savings
- By converting all forms of geometry no data is lost, eliminating the time required to recreate missing data
- With over 20 years industrial use Theorem's product robustness and quality is well proven, reducing your business risk

This document will focus specifically on guidance for the use of the CADverter for CATIA V5i to Parasolid product. For information regarding any of Theorem's product ranges please contact sales@theorem.com

Getting Started

Documentation

The latest copy of this documentation can be found on our web site at:

<http://www.theorem.com/Documentation>

Each product has a specific link that provides user documentation in the form of PDF and Tutorials.

Installation Media

The latest copy of Theorem software can be found via our web site at:

<http://www.theorem.com/Product-Release-Notes>

Each product has a specific link to the Product Release Document, which contains a link to the download location of the installation CD.

Alternatively, you can request a copy of the software to be shipped on a physical CD.

Installation

The installation is run from the CD or ZIP file download provided.

Currently, there are 2 distinct installation stages that are required.



To install the translator, select the **CAD_23.1_CSIPS_WIN.01.msi** file and follow the installation process. For a full guide to the process, please see our 'Translator Installation Process' demonstration video located [here](#).



In addition, the Theorem Unified Interface will also need to be installed. The installation process is the same as for the Translator. For a full guide to the process, please see our 'Translator Installation Process' demonstration video located [here](#).

License Configuration



In order for the translation to run successfully, the Theorem license file provided to you needs to be configured using FlexLM. For a full guide to this process, please see our 'FlexLM License Set Up and Configuration' demonstration video located [here](#).

Running the Product

Once configured and licensed, the product is ready to be run.

There are 2 distinct ways of running the translator:

- Via the Theorem Unified Interface



- The Unified Interface offers a Desktop Environment that allows CAD and Visualization data to be viewed pre and post translation

- Via the Command Line



- The Command Line Interface provides a direct method of invoking the translator. It can be used via a DOS shell or called via a third party application as part of a wider process requirement.


Using the Product

Default Translations

Default Translation – via the Unified Interface


The Unified Interface can be started via the Start Menu – if a shortcut was added during installation.

<UI_installation_directory>\bin\Unified_Interface.cmd




The following interface will be launched:

The default layout is split into 4 primary areas, which can be altered to the users prefer:




The simplest way to translate from CATIA V5 to PARASOLID is to drag a file from the file Browser Pane on to the Active Configurations for the translation you require.



On completion, the Unified Interface will display the activity information and details from the log file created during the translation, if requested, in the Translation Activity and Output Log panes, respectively.

The generated output data can be located by selecting the translation from the Activity pane and opening the output folder:



Default Translation – via the Command Line

Running a translation via the command line can be carried out via the ***cad_run.cmd*** file located in the **<installation_directory>\bin** directory. The format of the command is as follows when translating from CATIA V5 to PARASOLID:

<Translator_installation_directory>\bin\cad_run.cmd CATIA5i_Parasolid -i <input_file> -o <output_file>

The example above will translate a CATIA V5 sample file provided within the installation and produce the following screen output:

```

Command Prompt
Microsoft Windows [Version 10.0.17763.678]
(c) 2018 Microsoft Corporation. All rights reserved.

U:\>"C:\Program Files\Theorem\22.2\C5IPS\bin\cad_run.cmd" Catia5i_Parasolid -i "C:\Program Files\Theorem\22.2\C5IPS\samp
les\catia5\NIST\nist_ctc_01_asme1_ct5210_rd.CATPart" -o C:\Temp\nist_ctc_01_asme1_ct5210_rd

*****
* Copyright Theorem Solutions Limited                               *
* *                                                                 *
* Catia5i To Parasolid                                             *
* *                                                                 *
* Version 22.2.001                                                 *
*****

Tue Sep 10 17:00:28 2019

Input file      : C:\Program Files\Theorem\22.2\C5IPS\samples\catia5\NIST\nist_ctc_01_asme1_ct5210_rd.CATPart
Output file     : C:\Temp\nist_ctc_01_asme1_ct5210_rd.X_T
Progress file   : C:\Users\martin\AppData\Local\Temp\tscprogressb6.log

List of gco entities :-
-----
Type           Total      Standalone  Subordinate
-----
Curves        414              414
Surfaces       71              71
Planes         80              80
Faces          151             151
Edges          414              414
Vertices       270              270
Bsolids        1              1
-----

*****
* Parasolid file successfully created ...                          *
* C:\TEMP\NIST_CTC_01_ASME1_CT5210_RD.X_T                        *
*****
    
```

The file will be output to the target location. In this case:

C:\Temp\nist_ctc_02_asme1_ct5210_rd.X_T

Translator Customization

The Theorem translator allows the information that is read from the source system and written to the target system to be tailored via a set of user specified arguments. Commonly used arguments are supported via the Unified Interface, with Advanced Arguments being described within this document for use in the Unified Interface or via the Command Line invocation.


Common Options for CATIA V5i to Parasolid

Within the Configuration Manager pane of the Unified Interface, arguments that can be specified when publishing CATIA V5 data into Parasolid are grouped into the following areas:

- CATIA V5i Read – Those arguments that affect how data is read from CATIA V5
- Parasolid Write – Those arguments that affect how the data is written to Parasolid
- Entity Mask – Those arguments that allow specific read entities to be masked
- General – Those arguments that are common to ALL Publishing activities regardless of source data

CATIA V5i Read Arguments

The image below shows the CATIA V5i Read arguments that are available, with their default settings:



Option Name	Value
Retain Assembly Structure	<input checked="" type="checkbox"/>
Read Face Colours	<input checked="" type="checkbox"/>
Read Hidden Data	<input type="checkbox"/>


Each of these options is described below:

Option	Description
Retain Assembly Structure	Retain the assembly structure. Default is ON. <ul style="list-style-type: none"> ○ Command Line Syntax <ul style="list-style-type: none"> ▪ <i>offditto</i> (to disable) – reduces an assembly to a single Part
Read Face Colours	Process face colours in preference to body colours. Default is ON. <ul style="list-style-type: none"> ▪ Command Line Syntax <ul style="list-style-type: none"> ▪ <i>disable_face_colours</i> – to turn off

Read Hidden Data	Allow selective data types to be read regardless of hide/show state. Default is OFF. <ul style="list-style-type: none"> Command Line Syntax <ul style="list-style-type: none"> <code>read_hidden_geometry</code>
-------------------------	---

Parasolid Write Arguments

The image below shows the PARASOLID Write arguments that are available, with their default settings:




Each of these options is described below:

Option	Description
Parasolid Version Number	Parasolid version number to 'Save As' (default latest - 32) <ul style="list-style-type: none"> Command Line Syntax <ul style="list-style-type: none"> <code>psver <number></code>

CATIA V5i to Parasolid Entity Mask Arguments

The image below shows the CATIA V5i to Parasolid Entity Mask arguments that are available, with their default settings:




Each of these options is described below:

Option	Description
Mask File	<p>Specifies the Mask File to be written to, that can be referenced by future translations. A Mask file MUST be specified if masking is required. The first line in this file is OFF ALL ENT:</p> <ul style="list-style-type: none"> Command Line Syntax: <ul style="list-style-type: none"> <i>Mask <filename></i>
Entity Types Translated	<p>Specifies a selection list from which to select which entity types are to be processed. The following types are available:</p> <p>"SOL" - Masks any 3D entity "SKIN" - Masks any 2D entity "CUR" - Masks any 1D entity "POI" - Masks any 0D entity</p> <p>"AXIS" - Masks Axis Systems "ISOL" - Masks Isolated facetted solids "CCRV" - If on creates a CCRV curve for wire frame edges that have more than one supporting curve "TEXT" - Masks PMI Text</p> <ul style="list-style-type: none"> Command Line Syntax: <ul style="list-style-type: none"> <i>Add any of the above to the specified mask file, one entry per line prefixed by the word ON,</i> <p><i>e.g.:</i></p> <p>ON POI</p> <p><i>to ensure they are considered in the translation</i></p>
Layers Translated	<p>Specifies a selection list from which to select which layers are to be processed.</p> <ul style="list-style-type: none"> Command Line Syntax: <ul style="list-style-type: none"> <i>A single entry of ON ALL LAY Must precede any Layer Mask command.</i> <i>Add a list or range of numbers representing layer to be processed to the specified mask file to ensure they are NOT considered in the translation</i> <p><i>e.g.:</i></p> <p>OFF LAY 114,149,166,167,168</p>
Convert No Show Geometry	<p>Enables Hidden geometry to be processed (<i>Default = Off</i>)</p> <ul style="list-style-type: none"> Command Line Syntax: <ul style="list-style-type: none"> <i>Add the following entry to the Mask file</i> <p>ON NOSHOW GEO</p>
Convert No Show Structure	<p>Enables Hidden Assembly Structure to be processed (<i>Default = Off</i>)</p> <ul style="list-style-type: none"> Command Line Syntax: <ul style="list-style-type: none"> <i>Add the following entry to the Mask file</i>

	ON NOSHOW STR
Convert No Show AXIS	<p>Enables Hidden Axis Systems to be processed (<i>Default = Off</i>)</p> <ul style="list-style-type: none"> Command Line Syntax: <ul style="list-style-type: none"> Add the following entry to the Mask file ON NOSHOW AXI

CATIA V5i to Parasolid General Arguments

The image below shows the General arguments that are available, with their default settings:



Each of these options is described below:

Option	Description
Mass Properties	<p>CATIA V5 mass properties (volume/area CofG) are read and any applied materials, using this option, in cases where a part has multiple solids, volume and area values are summed, but CofG data is invalid.</p> <ul style="list-style-type: none"> Command Line Syntax <ul style="list-style-type: none"> <i>mprops</i>
Advanced	<p>Allows any of the Command Line Advanced arguments documented to be passed to the Unified Interface invocation.</p>


Common Options for Parasolid to CATIA V5i

Within the Configuration Manager pane of the Unified Interface, arguments that can be specified when publishing Parasolid into CATIA V5 data are grouped into the following areas:

- **Parasolid Read** – Those arguments that affect how data is read from Parasolid
- **Catia5i Write** – Those arguments that affect how the data is written to Catia5
- **Entity Mask** – Those arguments that allow specific read entities to be masked
- **General** – Those arguments that are common to ALL Publishing activities regardless of source data

Parasolid Read Arguments

The image below shows the CATIA V5i Read arguments that are available, with their default settings:




Each of these options is described below:

Option	Description
Retain Assembly Structure	Retain Assembly Structure. Default is ON. <ul style="list-style-type: none"> ○ Command Line Syntax to disable (remove structure) <ul style="list-style-type: none"> ▪ <i>noditto</i>
Output Part Units	Define the output part units (default mm) <ul style="list-style-type: none"> ○ Command Line Syntax <ul style="list-style-type: none"> ▪ mm ▪ inches ▪ metres

Catia5i Write Arguments

The image below shows the CATIA V5I Read arguments that are available, with their default settings:




Each of these options is described below:

Option	Description
Write Catia5 Version	<p>Save a specified version of Catia5 data (default 28 (2018))</p> <ul style="list-style-type: none"> ○ Command Line Syntax <ul style="list-style-type: none"> ▪ <code>save_catia5_version <version></code> <p>Where versions are :</p> <ul style="list-style-type: none"> ▪ R25 ▪ R26 ▪ R27 ▪ R28
Disable Points	<p>Disable Point processing (default is OFF)</p> <ul style="list-style-type: none"> ○ Command Line Syntax to disable Points <ul style="list-style-type: none"> ▪ <code>disable_points</code>
Disable Wireframe Processing	<p>Disable Wireframe processing (default is OFF)</p> <ul style="list-style-type: none"> ○ Command Line Syntax to disable Wireframe <ul style="list-style-type: none"> ▪ <code>disable_wireframe</code>
Create CGR	<p>Create a tessellated CGR file output (default is OFF)</p>

	<ul style="list-style-type: none"> ○ Command Line Syntax to create a CGR <ul style="list-style-type: none"> ▪ Create_CGR
--	---

Parasolid to CATIA V5i Entity Mask Arguments

The image below shows the Parasolid to CATIA V5i Entity Mask arguments that are available, with their default settings:




Each of these options is described below:

Option	Description
Mask File	<p>Specifies the Mask File to be written to, that can be referenced by future translations. A Mask file MUST be specified if masking is required. The first line in this file is OFF ALL ENT:</p> <ul style="list-style-type: none"> ▪ Command Line Syntax: <ul style="list-style-type: none"> ▪ <i>Mask <filename></i>
Entity Types Translated	<p>Specifies a selection list from which to select which entity types are to be processed. The following types are available:</p> <p>"SOL" - Masks any 3D entity "SKIN" - Masks any 2D entity "CUR" - Masks any 1D entity "POI" - Masks any 0D entity</p> <p>"AXIS" - Masks Axis Systems "ISOL" - Masks Isolated facettted solids "CCRV" - If on creates a CCRV curve for wire frame edges that have more than one supporting curve "TEXT" - Masks PMI Text</p> <ul style="list-style-type: none"> ▪ Command Line Syntax: <ul style="list-style-type: none"> ▪ <i>Add any of the above to the specified mask file, one entry per line prefixed by the word ON,</i> <p><i>e.g.:</i></p> <p><i>ON POI</i></p>

to ensure they are considered in the translation

Parasolid to CATIA V5i General Arguments

The image below shows the General arguments that are available, with their default settings:



Each of these options is described below:

Option	Description
Mass Properties	<p>CATIA V5 mass properties (volume/area CofG) are read and any applied materials, using this option, in cases where a part has multiple solids, volume and area values are summed, but CofG data is invalid.</p> <ul style="list-style-type: none"> Command Line Syntax <ul style="list-style-type: none"> <i>mprops</i>
Advanced	<p>Allows any of the Command Line Advanced arguments documented to be passed to the Unified Interface invocation.</p>

Command Line Advanced Arguments

Any of the Advanced arguments can be added to the Command Line Invocation or to the General->Advanced field when run from within the User Interface.

CATIA V5i to Parasolid Advanced Arguments

Option	Description
Small Curves	Report Small curves as errors. Default is OFF. <ul style="list-style-type: none"> ○ Command Line Syntax to enable <ul style="list-style-type: none"> ▪ <code>small_curves</code>
Extend Nurb Surfaces	Extends NURBS surfaces beyond face limits for curve projection (default state) <ul style="list-style-type: none"> ○ Command Line Syntax <ul style="list-style-type: none"> ▪ <code>no_extend_nurb</code> - (<i>Dont extend NURBS surfaces to face limits</i>) ▪ <code>extend_nurb <int></code> - (trims NURBS surfaces to <code><int> * 0.0001</code> face extents in u and v)
Remove Groups	Remove Group entities into assembly structure. Default is OFF. <ul style="list-style-type: none"> ○ Command Line Syntax to enable <ul style="list-style-type: none"> ▪ <code>remove_groups</code>
Use Ref Name	Uses file name from input system to name files Default is OFF. <ul style="list-style-type: none"> ○ Command Line Syntax to enable <ul style="list-style-type: none"> ▪ <code>use_ref_name</code>
Simplify Curves	Convert NURBS curves to conics. Default is OFF. <ul style="list-style-type: none"> ▪ Command Line Syntax to enable <ul style="list-style-type: none"> ▪ <code>simplify_curve</code>
Convert Curves to NURBS	Convert curves to NURBS. Default is ON. <ul style="list-style-type: none"> ▪ Command Line Syntax to disable <ul style="list-style-type: none"> ▪ <code>dont_convert_curves</code>
Conversion Tolerance	A secondary argument to 'Convert Curves' defining the conversion tolerance. Default is 0.00001 <ul style="list-style-type: none"> ▪ Command Line Syntax <ul style="list-style-type: none"> ▪ <code>convert_curve_tol 0.00001</code>
Convert Surfaces to NURBS	Process data (read) types as NURBS. Data type is selected from options. Default is All. i.e. convert ALL surfaces to NURBS <ul style="list-style-type: none"> ▪ Command Line Syntax <ul style="list-style-type: none"> ▪ <i>None:</i> <code>dont_convert_surfaces</code> ▪ <i>Fillets:</i> <code>dont_convert_fillets.</code> ▪ <i>Spheres:</i> <code>dont_convert_spheres</code>

	<ul style="list-style-type: none"> ▪ <i>Toruses: dont_convert_torus</i> ▪ <i>All: convert_surfaces</i> <p>e.g. <i>dont_convert_spheres + dont_convert_fillets</i> will leave fillets and spheres in their analytical form.</p>
Convert Torus to NURBS	<p>Even when data is read as NURBS data, the Torus types are converted to NURBS by default, this can be disabled using the command line. Default is ON.</p> <ul style="list-style-type: none"> ▪ Command Line Syntax to disable <i>dont_convert_torus</i>
Conversion Tolerance	<p>A secondary option to 'Convert Surfaces to NURBS'. Defines the conversion tolerance. Default is 0.00001.</p> <ul style="list-style-type: none"> ▪ Command Line Syntax <ul style="list-style-type: none"> ▪ <i>convert_surface_tol 0.00001</i>
Trim Face Surfaces	<p>Trims face surfaces. Default is ON.</p> <ul style="list-style-type: none"> ▪ Command Line Syntax to disable. <ul style="list-style-type: none"> ▪ <i>dont_trim_surfaces</i>
Process Large Faces	<p>Enable reading of faces larger than 1km. Default is OFF.</p> <ul style="list-style-type: none"> ▪ Command Line Syntax to enable. <ul style="list-style-type: none"> ▪ <i>allow_large_faces</i>
UDF Axis Systems	<p>Enable reading of User Defined Axis systems. Default is OFF.</p> <ul style="list-style-type: none"> ▪ Command Line Syntax to enable. <ul style="list-style-type: none"> ▪ <i>read_udf_axis</i>
Graphical Read	<p>By default the BREP data will be read. It is possible to read the CATIA V5 data as a graphical representation using this option. Default is OFF.</p> <ul style="list-style-type: none"> ▪ Command Line Syntax to enable <ul style="list-style-type: none"> ▪ <i>enable_graphical</i>
Filter Geometry	<p>It is possible to filter large planes (construction planes) larger than a given size using (default being 1000 meters)</p> <ul style="list-style-type: none"> ▪ Command Line Syntax <ul style="list-style-type: none"> ▪ <i>filter_large_geom <meters></i> <p>There is a special case for PLANES (typically construction planes) which by default are not read, these can be enabled using</p> <ul style="list-style-type: none"> ▪ Command Line Syntax <ul style="list-style-type: none"> ▪ <i>read_planes</i>
Parasolid Tolerant Modelling	<p>Enable Parasolid Tolerant Modelling. Default is ON.</p> <ul style="list-style-type: none"> ▪ Command Line Syntax to disable <ul style="list-style-type: none"> ▪ <i>nopstolmodel</i>
Sew Parasolid Bodies	<p>Enabled Sewing of Parasolid Bodies. Default is ON.</p> <ul style="list-style-type: none"> ▪ Command Line Syntax to disable <ul style="list-style-type: none"> ▪ <i>nosew</i>
Incremental Sewing	<p>Enable incremental Sewing. Default is ON.</p> <ul style="list-style-type: none"> ▪ Command Line Syntax to disable <ul style="list-style-type: none"> ▪ <i>no_sew_increm</i>

Incremental Sewing Iterations	No. of iterations for incremental Sewing (default 5) <ul style="list-style-type: none"> Command Line Syntax <ul style="list-style-type: none"> <i>sew_increm <number></i>
Explode Solids to Faces	Explode Solids to Individual Faces. Default is OFF. <ul style="list-style-type: none"> Command Line Syntax to enable <ul style="list-style-type: none"> <i>split_brep</i>
Split Discontinuous Surfaces	Split Discontinuous Surfaces. Default is ON. <ul style="list-style-type: none"> Command Line Syntax to disable <ul style="list-style-type: none"> <i>no_brep_prep</i>
Force body creation	Force body creation (No check of Parasolid entities - Default is ON) <ul style="list-style-type: none"> Command Line Syntax to disable <ul style="list-style-type: none"> <i>check</i>
Fix Degenerate Edges	On face create failure, check and fix any degenerate edges. Default is ON. <ul style="list-style-type: none"> Command Line Syntax to disable <ul style="list-style-type: none"> <i>no_fix_degen</i>

Parasolid to CATIA V5i Advanced Arguments

Option	Description
Convert surfaces to NURBS	Read surfaces as NURBS surfaces (else read in native form). Default is ON. <ul style="list-style-type: none"> Command Line Syntax to disable <ul style="list-style-type: none"> <i>noprep</i>
Convert Edge Curves to NURBS	Read edge curves as NURBS curves (else read in native format) (default ON) <ul style="list-style-type: none"> Command Line Syntax to disable <ul style="list-style-type: none"> <i>rd_native_edge</i>
Mass Props Volume Tolerance	Set tolerance for volume percentage comparison to consider as success (default 1.0) <ul style="list-style-type: none"> Command Line Syntax <ul style="list-style-type: none"> <i>vol_tol <value></i>
Mass Props Area Tolerance	Set tolerance for area percentage comparison to consider as success (default 0.5) <ul style="list-style-type: none"> Command Line Syntax <ul style="list-style-type: none"> <i>area_tol <value></i>
Mass Props CofG Tolerance	Set tolerance for Centre Of Gravity (CofG) percentage comparison to consider as success (default 1.0) <ul style="list-style-type: none"> Command Line Syntax <ul style="list-style-type: none"> <i>cog_tol <value></i>